







K51M Series

K51M Series (Except for K51M-400)

K51M-400





STEP 1.




Remove the original set screws.

STEP 2.



STEP 3.



Install the new set screws provided.

